



BDSXR Drive Shower
for Bravo XR, XR Sportmaster,
XR3, XZ1 ALL W/ INTERGRATED TOP W/ RIBBED CAP & STUDS

BDSXR Drive Shower Cap Installation Instructions:

1. Slide hose into rear of the drive shower. Install mounting clip.
2. DO NOT remove the factory nuts from the studs. Screw the hex adapters out to the end of the studs, until they bottom out with the factory nuts.
3. Place shower cap on top of hex adapters.
4. Install the 3/8 bolts thru the top of the shower cap. Torque bolts to 25 ft. lbs.
5. Cut out template and tape to either the right or left side of the cavitation plate. If you have a swim step you need to check to make sure drive does not hit step when raised, adjust position accordingly.
6. Center punch holes and drill 1/2" hole, then 9/32" as shown in the template.
7. Remove burrs in drilled holes.
8. Place hose thru the 1/2" hole and mount with 1/4" bolt, nut & washer. Torque to 120-125 in. lbs

Livorsi Marine Inc. 715 Center Street Grayslake IL 60030
www.livorsi.com P: 847-752-2700 F: 847-752-2415 info@livorsi.com