

Quick Pin Base Installation Instructions

Tools Required

- Drill
- Drill bit or Hole saw $\frac{3}{4}$ inch
- Allen wrench $\frac{3}{8}$ inch
- Socket or wrench $1 \frac{1}{8}$ inch
- Quality marine sealant
- Masking tape



Installing quick pin base's QRBSB-150
& QRBSB-225

Choose a suitable location and verify clearances and no obstructions
Drill a $\frac{3}{4}$ inch hole in desired location and remove any excess material from mounting hole



Note:

It is best to apply masking tape before drilling

Apply a quality marine sealant to the surface and insert the quick pin base



From the bottom of the quick pin base, install the supplied washer and 1 1/8th mounting nut onto the quick pin base



Using a 3/8" Allen wrench, hold the quick pin base and tighten the 1 1/8th mounting nut.



Clean away any excess sealant from the quick pin base
Installation is complete

Optional drain fitting (QRFDHF)



NOTE:

3/16" drain hose is not included

3/16" ID hose
1/4" NPT