


## Mechanical Gauges Applying Torque to Fittings

Part Numbers beginning with: DCM or DCSM

1. Use multiple wrenches to torque fitting. **Recommended torque 5 to 7 in-lbs.** Over torquing will damage gauge. **NOTE: Damage due to over torquing is not covered by warranty.**



2. Do not over torque the fitting or mounting screws. This will **void the warranty.** See below examples of an over torqued gauge.

